

[®]
dreamGEAR

TURBO GT

USER'S GUIDE



www.dreamgear.net

SET-UP INSTRUCTIONS

1. The Turbo GT requires 4 “AA” batteries. Remove the battery lid and place the 4 “AA” batteries inside. Replace the battery lid.
2. Plug the Audio cable (red end) into your video displays audio input (red input) and plug the Video cable (yellow cable) into your video display’s video input (yellow input).
3. Power on the Turbo GT by switching the power switch on the Controller & Receiver pack to the “ON” position.
4. Confirm your video display is set to the proper video input (for example if you plug the Turbo GT into your video displays input 1, switch your video display to input 1).
5. From the game’s menu, highlight the game you would like to play and press the start button.

Battery warning:

1. Do not mix old and new batteries.
2. Do not mix alkaline and rechargeable batteries.
3. Always have an adult insert or change batteries.

Age limit:

1. This product is designed for children 5 and older.

PACKAGE CONTENTS

- Turbo GT Wheel
- Instruction Manual
- Warranty Card
- Product Registration Card

[®]
dreamGEAR



**FOR TECHNICAL SUPPORT PLEASE CONTACT:
1-877-999-DREAM**

GAMEPLAY INSTRUCTIONS:

To begin any one of the 50 games, select the game you wish to play from the game menu and press the start button.

1. BIG RACING: The International Racing Championship is on the line! You're at the wheel of a supercharged car, weaving in and out of the pack. Don't bump into other cars and watch out for dangerous obstacles!

Directional Pad: Up and Down

A button: Accelerate

B button: Brake

2. VR RACING: You're racing your motorcycle against time on a track crowded with other riders! Reach the destination within the time limit and advance to the next level. You can race your motorcycle at 4 exciting locations: Ancient Egypt, Modern City, Suburb and Seashore.

Steering Wheel or Directional Pad: Move left or right

A button: Accelerate

B button: Brake

Blue button: slower speed

3. FAST RACE:

Fasten your seatbelt and get ready for an exciting road! Avoid all the other cars and obstacles by careful driving and skillful jumps.

Steering Wheel or Directional Pad: Move left or right

A button or Blue button: Jump

Up direction: Accelerate

4. GP RACE:

Race your motorcycle through the city street. Along the way, pick up fuel to increase your score and keep from running out of gas. Avoid obstacles and other motorcycles or you'll crash. If you can reach the destination, you'll advance to the next level!

Steering Wheel or Directional Pad: Move left or right

A button: Accelerate

B button: Normal Speed

5. BUMP CAR:

You're driving on a bumpy road full of broken logs, jagged stones, and even bombs! You can drive on or off the road, but going overland will really slow you down. Can you make it home safely?

Steering Wheel or Directional Pad: Move left or right

A button: Accelerate

B button: Jump

6. DUMP LORRY RACE:

You must race against time, guiding your 4x4 over a long road. Watch out for sharp turns and other drivers. Be careful, it takes speed and skill to win the race!

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button: Brake

7. EXCEL RACING:

Gather all of the flags and return to the starting line before being tagged by one of the other racers. You have a limited supply of bombs you can use to hold back your opponents. You lose the game if you run into bombs or collide with other racers.

Directional Pad: Move car in 4 directions

B button: Position the bomb

8. ROAD STAR:

If you thought the roads were bad in your town, wait until you face the conditions on this cross-country marathon! You'll need all your driving skills and luck as you race over some very bad roads!

A button: Hold to set acceleration, release to start jump!

Blue button: Hold to set acceleration, release to start jump slowly

9. GEAR RACE:

You're racing against time over a long wooden bridge. Bump off a green racer to score 100 points. Pick up canisters to score 50 points and to add 5 more seconds to your time. Be careful not to hit the wooden bridge! Race until time runs out and see how many points you can score!

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button or left trigger: Brake

10. MOTOR RALLY:

Race your motorcycle against time, but watch out for other motorcycles and obstacles. If you reach the destination within the time limit, you will advance to the next level.

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button or left trigger: Brake

11. ROAD BUMPER:

Full Contact Motorcycle Racing is the future's most exciting-and dangerous-sport! While the clock is ticking, drive your motorcycle and ram the other riders!

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button or left trigger: Brake

12. RUNNER CAR:

You must race over a long city street before running out of fuel, but watch out for other racers and road hazards like rocks. Pick up money-bags to get 100 bonus points and scoop up "P" markers to add more fuel.

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button or left trigger: Brake

13. SPEEDY WAY-X:

The flag drops and you're racing against time through tropical jungles, city streets, lush fields, and quiet villages. Follow the twisting road and watch out for rocks, puddles, pedestrians, and other vehicles.

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button or left trigger: Brake

14. TRUCK RACE:

Your track is full of bricks you must deliver to the job site safe and sound. But with so many obstacles and people in the way, the trip is more complicated than you can imagine! Use your best driving skills and you'll win...if you're lucky!

Steering Wheel or Directional Pad: Move left or right

A button or right trigger: Accelerate

B button or left trigger: Brake

15. AERO ENGINE:

A fierce battle rages in outer space. You command a starship flying between the planets, trying to destroy the invading alien armada. Pick up one blue power sphere for double fire. Pick up two blue power spheres and you'll unlock triple fire!

Directional Pad: 8 directions

A button: Fire

Blue button: Continuous fire

16. BIRDIE NEST:

Balance the bird on the stick while catching its eggs. Sound too easy? You've obviously never tried to balance a bird on a stick! If you get hit by the droppings! 10 times, or the bird falls down, you lose!

Directional Pad: Move left and right

17. BOLT FIGHTER:

A purple-red fighter plane is bravely combating other different enemy fighter planes over the sky of ocean and continent.

Bolt Fighter is a one or two player game. Player two begins their game after player 1 has lost all their lives.

Directional Pad: 8 directions

A button or right trigger: Fire

Blue button: Continuous Fire

B button or left trigger: Fires secondary weapon

18. BUILD UP ROAD:

You must make a passage for all vehicles through the open land and around the rocks and trees to the final destination. You will need to construct road sections with your grapple dredge. Once you have successfully complete the task, the vehicle in the upper left corner will automatically drive to the final destination located in the bottom right corner.

Directional Pad: Move in 8 directions

A button: Selects road piece, and places road piece

Right trigger: Undo's last move

19. CATCH THE EGG:

Catch the falling eggs, but beware, the evil birds also randomly throw down bombs. Avoid the bombs and you win!

Directional Pad: Move left and right

20. CHALLENGE 100:

You must move back and forth, dropping from one platform to the next, while avoiding the deadly spikes. Watch out for surprises and don't get crushed against the top of the screen or fall off the bottom!

Directional Pad: Move left and right

21. CRAZY HIT:

There are giant gophers living under your new house and running your beautiful lawn! Once they pop up from their holes, you must bop them on the head. The more gophers you bop, the more points you earn.

Directional Pad: Move in 8 directions

A button, blue button or right trigger: Hit enemy

Use the directional pad plus any one of the hit enemy buttons to aim and strike at the enemy.

22. DART CHAMPION:

The target is coming from different direction; shoot the target when it overlaps the square shown on screen. Get more points by shooting more targets within the time limit.

Shoot the white targets and you get 100 points.

Shoot the blue targets and you get 300 points.

All buttons: use any button to fire at the targets

23. DRAGON FIRE:

Guide the Dragon to the fireballs. The more fireballs you get, the longer the Dragon becomes. If the Dragon bumps into barriers or the edge, game is over.

Directional Pad: Move in 4 directions

24. ELFLAND:

Destroy the monster that is the same color as your elf to save Elfland. If you want to eliminate other monsters, just jump into the different paint buckets and color yourself the same as the monster! If a monster of a different color hits you, you'll lose a life.

Directional Pad: Move left and right

A button: Jump

25. FIRE FIGHTER:

Position the spring bed in order to bounce the falling fire fighter. During the bounce, he can put out the fires in the house or rescue the people calling for help. If all the fires are put out or all the trapped people are saved, you advance to the next level.

Directional Pad: Move left and right

A button: Jump

26. FISH CATCHER:

The fish are jumping randomly. Catch the red fish, but avoid the black ones or you'll lose your power.

Directional Pad: Move left and right

A button, blue button or right trigger: throws hand to catch fish

27. GOLDEN ARROW:

Test your marksmanship as you shoot arrows at the moving targets. Press the A button to increase the angle of your shot and release it to fire your arrow. Pay attention to the wind speed and try to hit the center of the target!

A button or right trigger: Set angle/Fire arrow

B button: Set the wind strength

28. GRASS CUTTER:

It is your turn to mow the lawn. You must make sure that you mow every square inch of the yard by using your lawnmower before time runs out but beware of the cloud. The cloud will make the grass grown back.

Directional Pad: Move in 4 directions

29. INSECT CHASE:

It is a beautiful sunny day, perfect weather for catching butterflies. You must use your net to catch all the butterflies. When you catch one, a rewarding text message will be shown on the screen.

Directional Pad: Move in 8 directions

30. JEWEL MASTER:

As the jewels fall in groups of three, try to line up jewels of the same shape and color. Try your best to wipe off all the jewels of the same color and shape.

Directional Pad: Move left and right

Directional Pad: Push down to speed up the falling jewels

A button, B button or right trigger: Changes sequence of three jewels

31. JUMPING BALL:

A robot automatically serves 20 balls to you. Hit each ball back at the three panels. When you hit a panel, it spins and you will score 10 points. Get the same picture showing on all three panels and you'll score 100 points! After all the balls have been served, the game is over.

A button or right trigger button: Hit ball

32. LAST CABRA:

Defeat the enemy air force. Watch out for battle stations hidden on land. Get through the enemy defenses and you'll encounter the mega-battle plane. Defeat this flying fortress and you will win the game! Along the way, Pick up "S" ammo to project scattering bullets.

Directional Pad: Move in 8 directions

A button: Fire weapon

Blue button: Continuous fire

33. LOOP TENNIS:

In this unusual game, you've got to bounce the ball from one racquet to another. Be sure to time your shot so the ball will land properly on the other racket. If you miss, you'll lose the ball!

A button: Soft bounce

B button: Hard bounce

34. MOVE FUN:

There are several types of objects displayed on the screen. Move them so any three or more of the same objects are connected in a straight line.

Directional Pad: Move cursor

A button, or blue button: Confirm the selection

35. OCEAN QUEST:

Race your powerboat along the river. If someone gets in your way, you move on to the next level when your boat reaches the destination within the time limit.

Directional Pad: Move up and down

A button: Accelerate

B button: Brake

36. PAINT MASTER:

Paint the entire runway but beware of the enemy's attack. If you complete a full square, you will move to the next level.

Directional Pad: Move in 4 directions

37. PET SHOP:

Sometimes those barking dogs really get on your nerves! You control the cat on the left side. Try to hit the dog on the other side of the fence with the ball. If you hit the dog enough times, you win! Hit the A once to start charging up for your throw and again to throw the ball.

A button: Starts power meter, and throws ball

38. PINBALL TRACK:

Roll the pinball through the pipeline. Keep an eye open for keys, you'll need them to open the locked gates blocking your path. Open all the locks and you'll advance to the next round! Avoid the holes in the track or you'll fall through and lose a life.

Directional Pad: Move in 8 directions

39. PUSH THE BALL:

Will you try to beat your opponent with a bank shot or knock the ball past him before he knows what's coming? The choice is yours!

Directional Pad: Move in 8 directions

40. RACING BOAT:

Race your boat down the river as far as you can before running out of fuel. Watch out for other boats and hazards, but try to scoop up the green fuel tanks floating in the water! It takes speed and reflexes to win!

Directional Pad: Move left and right

A button: Accelerate

B button: Brake

41. SEA WAR:

You've been ordered to clear the area and make it safe for the rest of the fleet! Avoid enemy attacks and destroy as many of their ships as you can.

Directional Pad: Move left and right

A button: Fire

Blue button: Fires weapon rapidly

42. SMART ESCAPE:

Collect magical items to defeat monsters. If you eliminate all the monsters, you'll be given a key to the next level. Each time you clear a level, you get a password so you can go directly there from the starting screen.

Directional Pad: Move in 4 directions

A button or blue button: Fire

B button or yellow button: Use the weapon to hold back the monster's attack

Start: Change the tool

43. SPACE CASTLE: Use your ground defense shuttle to eliminate them before they land. There are 4 shelters to help protect you from the space monsters' attack, but you cannot fire from behind the shelter.

Directional Pad: Move left and right

A button or blue: Fires weapon

44. SPIN BALL:

Roll the ball down the track to reach your destination within the given time. When you arrive at your destination and pick up the key, you will advance to the next level. During the course you can pick up other helpful objects along the way to gain extra points.

Directional Pad: Move in 4 directions

45. STAR ALLEY:

Fight your way through waves of enemy fighters in search of the rebel leader. When you find him, shoot him down in the name of the Emperor and you'll advance to the next level.

Directional Pad: Move in 8 directions

A button: Fire

Blue button: Continuous fire

46. SUPER SURFING:

Hit the red flag before time runs out but beware of other surfboarders and obstacles, like swimmers, motorboats, kayaks and seagulls. The more red flags you hit, the more points you get. If you hit any surfboarders or obstacles, you will lose a life.

Directional Pad: Move left and right

A button or blue button: Jump

47. ULTRA DOGGY:

Your dog is trying to get home by crossing busy streets. Along the way, it needs to collect keys scattered throughout the roads. Your dog can pick up other helpful objects along the way to increase its speed or gain extra points. Beware of the cars, wagons and other obstacles. When your dog gets all the keys, it can unlock the gates and go home.

Directional Pad: move in 4 directions

48. VALIANT RESCUE:

Blast them out of the skies and destroy their bases on the ground if you want to save the human race from extinction!

Directional Pad: Move in 8 directions

A button: Shoot at the flying objects

B button: Shoot at the ground objects

Blue button: Continuous shooting at the flying objects

49. WISON: Place the puzzle pieces in the square so each piece fits perfectly next to the others. If you can fill the board, you win!

Directional Pad: Move in 4 directions

A button or blue button: Choose and change the direction of the piece

B button or yellow button: Confirm and position the piece

Start: Return the selected piece to the side of the board

50. Zero Tiger:

An environmental lab created mutant pests that endanger the land. While facing an overspread of pest disaster, your mission is to fly your fighter plane and eliminate them all.

Directional Pad: Move in 8 directions

dreamGEAR®

20001 S. Western Avenue

Torrance, CA 90501

www.dreamgear.net